

**OLT-E/F**

**EPON OLT RELEASE 1.0**

**Network Management System Handbook**

# About this document

---

## Overview

OLT-E/F optical access equipment is a large-scale carrier-grade OLT (Optical Line Terminal). It complies with **IEEE802.3-2005** and **Technical Requirements for Access Network—Ethernet Passive Optical Network (EPON)**; It provides broadband, voice, IPTV, CATV and various kinds of integrated services for subscribers.

## Version

The document corresponds to product version as follows

Product name	Product version
OLT-E/F	V1.0

## Intended Audience

This document is intended for:

- Installation debugging engineer
- Field maintenance engineer
- System maintenance engineer
- Data configuration engineer
- Application developer

## Brief

This document describes the following about OLT-E/F

Chapter	Content
1 Overview	Introduce system structure, overall scheme and software hardware environment.
2 Quick Start	Introduce starting sequence, add device and using help.
3 Main Interface	Introduce main interface, main menu, toolbar, rolling log export bar and status bar.
4 System Management	Introduce system management, for example modify password, lock client, exit and db backup restore.
5 Equipment Management	Introduce basic processing of equipment.
6 Alarm Management	Introduce alarm processing..
7 Performance Management	Introduce real-time and history performance.
8 Security Management	Introduce security management method.
9 Topology Management	Introduce topology map management, physical topology and logical topology management.
10 OLT Detail	Introduce equipment control.
11 OLT Management	Introduce OLT configuration.
12 ONU Management	Introduce ONU configuration.
13 FAQ	Frequently asked questions.

## Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Class	Description
	Notice	Indicates a potentially hazardous situation, which if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.

	Warning	Indicates a hazard with a medium or low level of risk, which if not avoided, could result in minor or moderate injury.
	Note	Provides additional information to emphasize or supplement important points of the main text.

## Text Conventions

Symbol	Class	Description
/	or	One item is selected.
+	and	Two items or several items can be selected at the same time.
>	next	Multi-level menu is separated by ">".

## Change History

Changes between document issues are cumulative. Therefore, the latest document issue contains all changes made in previous issues.

## Version 1.0

This is the first official release.

# **Contents**

---

1.	Overview .....	1
1.1.	Profile .....	2
1.2.	System structure .....	2
1.3.	Overall scheme .....	3
1.4.	Software&hardware environment .....	4
2.	Quick start.....	5
2.1.	Starting sequence .....	6
2.2.	Add device .....	6
2.3.	Set the Trap Server.....	7
3.	Main interface .....	9
3.1.	Main interface .....	10
3.2.	Main menu .....	10
3.3.	Main toolbar .....	11
3.4.	Rolling log bar .....	11
3.5.	Status bar .....	11
4.	System management.....	13
4.1.	System management menu.....	14
4.2.	Lock client .....	14
4.3.	Modify password .....	15
4.4.	Data dump.....	16
4.5.	Db Backup and restore .....	16
4.6.	Exit .....	17
5.	Equipment management .....	19
5.1.	Equipment management menu.....	20
5.2.	NE query .....	20
5.3.	Scan IPC .....	21
5.4.	Review IPC .....	22
6.	Alarm management .....	23

6.1.	Alarm management menu .....	24
6.2.	Alarm and event query.....	24
6.3.	Alarm process rule .....	26
6.4.	Alarm sound .....	27
6.5.	Email notify configure.....	28
6.6.	Alarm parameter configuration .....	29
7.	Performance management.....	31
7.1.	Performance management menu .....	32
7.2.	Performance running configuration .....	32
7.3.	Performance collect task management .....	33
7.4.	Performance task data query.....	34
8.	Security management.....	37
8.1.	Security management menu.....	38
8.2.	User management .....	38
8.3.	Role management.....	40
8.4.	Permission management .....	41
8.5.	Online user.....	42
8.6.	Operation log .....	42
9.	Topology management .....	45
9.1.	Topology map operation .....	46
9.2.	Topology toolbar.....	46
9.3.	Auto layout .....	46
9.4.	Change name .....	47
9.5.	Search and locate .....	48
9.6.	Save position .....	48
9.7.	Domain and group management.....	49
9.8.	Device scan.....	50
9.9.	Add devices.....	51
9.10.	Physical topology map.....	51
10.	OLT detail .....	53

10.1.	OLT basic information .....	54
10.2.	Card list .....	55
10.2.1.	Provision card.....	55
10.2.2.	Delete card .....	56
10.2.3.	Reset card .....	56
10.3.	ONU list.....	57
10.3.1.	Authorize ONU .....	58
10.3.2.	Delete ONU .....	59
10.3.3.	Reset ONU .....	60
10.3.4.	Register ONU .....	60
10.4.	Invalid ONU list .....	60
10.5.	Batch authorize ONU .....	61
10.6.	ONU authorization Mode .....	62
10.7.	MAC white list .....	63
10.8.	LOID white list.....	66
10.9.	MAC bind .....	69
10.10.	ONU replace .....	69
11.	OLT management.....	71
11.1.	Delete device .....	72
11.2.	View management .....	72
11.2.1.	Chassis view .....	72
11.2.2.	Devices physical map.....	73
11.2.3.	Move .....	74
11.3.	Sync management.....	75
11.3.1.	Sync device .....	75
11.3.2.	Alarm sync .....	76
11.3.3.	Category sync.....	76
11.4.	Configuration.....	77
11.4.1.	Uplink configure .....	77
11.4.1.1.	Uplink port configure .....	77

11.4.1.2.	RSTP enable.....	78
11.4.1.3.	Port RSTP .....	79
11.4.1.4.	Trunk port link aggregation .....	80
11.4.2.	PON isolate.....	81
11.4.3.	IGMP .....	82
11.4.4.	QOS management.....	87
11.4.5.	MAC management.....	91
11.4.6.	Smart grid Server config.....	93
11.4.7.	EMS access control.....	94
11.4.8.	Performance statistic switch.....	95
11.4.9.	Optical detect switch.....	97
11.4.10.	Alarm threshold management.....	97
11.4.11.	Alarm template management.....	100
11.4.12.	Outer VLAN .....	101
11.4.13.	QINQ template .....	102
11.4.14.	QINQ profile binding.....	103
11.4.15.	System ONU ACL function .....	104
11.4.16.	Template configuration .....	105
11.4.17.	PON-Uplink bind.....	106
11.5.	Control command.....	107
11.5.1.	Upgrade system software.....	107
11.5.2.	Backup software .....	108
11.5.3.	Batch upgrade ONU .....	110
11.5.4.	IGMP management.....	111
11.6.	Operation .....	112
11.6.1.	Save device config.....	112
11.6.2.	Sync device time.....	112
11.6.3.	Restart .....	113
11.6.4.	Reset backup card.....	113
11.6.5.	Clear flash.....	114

11.6.6.	Force switch.....	114
11.6.7.	Export configuration files .....	115
11.6.8.	Import configuration files .....	116
11.6.9.	Export log files .....	117
11.6.10.	NE rename .....	118
11.7.	State Callbacks .....	118
11.7.1.	Open Batch Configure Capability .....	118
11.7.2.	MAC table .....	119
11.7.3.	ONU type and software and hardware versions .....	120
11.7.4.	Check OLT link status .....	121
11.7.5.	Slot work state info .....	122
11.7.6.	RSTP .....	123
11.7.6.1.	RSTP Bridge .....	123
11.7.6.2.	RSTP port info.....	124
11.8.	View current/History alarm.....	125
11.9.	View real-time performance.....	127
11.10.	Ping NE .....	127
11.11.	Telnet NE.....	128
12.	ONU management .....	131
12.1.	ONU detail.....	132
12.2.	NE rename .....	132
12.3.	View management .....	133
12.3.1.	Chassis view.....	133
12.3.2.	Device physical map .....	134
12.3.3.	Move.....	134
12.4.	Sync device.....	135
12.5.	Configuration.....	136
12.5.1.	ONU port MAC number limit .....	136
12.5.2.	RSTP enable .....	137
12.5.3.	DBA parameters management.....	138

12.6.	Control command.....	139
12.6.1.	ONU performance reset .....	139
12.7.	Operation(O) .....	139
12.7.1.	Reregister ONU .....	139
12.7.2.	Reset ONU .....	140
12.7.3.	Delete ONU .....	140
12.7.4.	Device to linkup .....	141
12.8.	State Call backs .....	142
12.8.1.	ONU port MAC table .....	142
12.8.2.	Device information.....	143
12.8.3.	Capability information.....	144
12.8.3.1.	FEC function .....	144
12.8.4.	Link test .....	145
12.8.4.1.	POTS port outer test .....	145
12.8.4.2.	POTS port inner test .....	146
12.9.	Operation(N) .....	147
12.9.1.	FE port loop back .....	147
12.9.2.	FE port auto-negotiation.....	148
12.9.3.	User business configuration.....	149
13.	FAQ .....	151

# **Figures**

---

Figure 1-1	System structure .....	3
Figure 1-2	General disposition .....	3
Figure 2-1	Login .....	6
Figure 2-2	Select protocol .....	7
Figure 3-1	The main interface .....	10
Figure 3-2	The main menu .....	10
Figure 3-3	The main menu .....	11
Figure 3-4	The rolling log bar .....	11
Figure 3-5	The status bar .....	11
Figure 4-1	System management menu.....	14
Figure 4-2	Lock client .....	14
Figure 4-3	Modify password.....	15
Figure 4-4	Data dump.....	16
Figure 4-5	Db backup and restore .....	17
Figure 4-6	Exit .....	18
Figure 5-1	Equipment management menu.....	20
Figure 5-2	NE Query .....	21
Figure 5-3	Scan IPC .....	21
Figure 5-4	Review IPC .....	22
Figure 6-1	Alarm management menu .....	24
Figure 6-2	Query alarm or event .....	25
Figure 6-3	Alarm rule.....	27
Figure 6-4	Alarm sound.....	28
Figure 6-5	Email notify config.....	29
Figure 6-6	Alarm parameter configuration .....	30
Figure 7-1	Performance management .....	32
Figure 7-2	Performance running configuration .....	33
Figure 7-3	Performance task management.....	34

Figure 7-4	Performance task result query .....	35
Figure 8-1	Security mgmt(S) .....	38
Figure 8-2	Create user .....	39
Figure 8-3	Role management.....	40
Figure 8-4	Permission management .....	41
Figure 8-5	Online user.....	42
Figure 8-6	Operation log .....	43
Figure 9-1	Toolbar .....	46
Figure 9-2	Auto layout .....	47
Figure 9-3	Change name .....	48
Figure 9-4	Search device .....	48
Figure 9-5	Create domain .....	49
Figure 9-6	Scan devices.....	50
Figure 9-7	Add devices.....	51
Figure 9-8	Physical topology map.....	52
Figure 10-1	Device detail .....	54
Figure 10-2	Provision card .....	55
Figure 10-3	Delete card .....	56
Figure 10-4	Reset card .....	56
Figure 10-5	ONU List .....	57
Figure 10-6	Add ONU.....	58
Figure 10-7	Successful authorizationn message.....	59
Figure 10-8	Failed Authorization fault message .....	59
Figure 10-9	Delete ONU .....	59
Figure 10-10	Delete successful message.....	59
Figure 10-11	Reset ONU .....	60
Figure 10-12	Register ONU .....	60
Figure 10-13	Invalid ONU list.....	61
Figure 10-14	Batch authorize.....	62
Figure 10-15	ONU authorized mode.....	63

Figure 10-16	Add white list.....	64
Figure 10-17	Batch Modify .....	65
Figure 10-18	MAC white list.....	66
Figure 10-19	Add LOID white.....	67
Figure 10-20	LOID Batch modify.....	68
Figure 10-21	LOID White list.....	68
Figure 10-22	MAC-LOID Bind.....	69
Figure 10-23	ONU Replace.....	70
Figure 10-24	Replace fault.....	70
Figure 11-1	Delete devices .....	72
Figure 11-2	Chassis view.....	73
Figure 11-3	Devices physical map.....	74
Figure 11-4	Move.....	75
Figure 11-5	Device sync .....	76
Figure 11-6	Alarm message.....	76
Figure 11-7	Category sync.....	77
Figure 11-8	Uplink port config.....	78
Figure 11-9	RSTP Enable .....	79
Figure 11-10	Port RSTP config .....	80
Figure 11-11	Trunk port link aggregation.....	81
Figure 11-12	PON port isolate .....	82
Figure 11-13	Global property .....	83
Figure 11-14	IGMP Auth template.....	83
Figure 11-15	FE Auth template .....	84
Figure 11-16	Group config .....	85
Figure 11-17	Prejoin.....	85
Figure 11-18	Cascade port .....	86
Figure 11-19	ONU Fast leave .....	86
Figure 11-20	Create QOS Template .....	87
Figure 11-21	QOS Template bind/unbind .....	88

Figure 11-22	Packets rate control .....	89
Figure 11-23	ONU Bandwidth .....	90
Figure 11-24	QOS priority .....	91
Figure 11-25	MAC Management.....	92
Figure 11-26	ONU Port mac number limit.....	93
Figure 11-27	Smart grid server config .....	94
Figure 11-28	EMS Access control.....	95
Figure 11-29	Card port statistic switch.....	96
Figure 11-30	ONU Port statistic switch.....	96
Figure 11-31	Optical detect switch.....	97
Figure 11-32	CPU usage threshold .....	98
Figure 11-33	Uplink port threshold.....	99
Figure 11-34	ONU Optical module threshold.....	99
Figure 11-35	Template management .....	100
Figure 11-36	Template bind/unbind .....	101
Figure 11-37	Outer vlan .....	102
Figure 11-38	Create QINQ template.....	103
Figure 11-39	QINQ Profile binding.....	104
Figure 11-40	System ONU ACL function .....	105
Figure 11-41	Template configuration .....	106
Figure 11-42	PON-Uplink Bind.....	107
Figure 11-43	Upgrade system software.....	108
Figure 11-44	Backup system software.....	109
Figure 11-45	Batch upgrade ONU .....	111
Figure 11-46	Flush IGMP configuration .....	111
Figure 11-47	Save current configuration.....	112
Figure 11-48	Update time .....	112
Figure 11-49	Restart device.....	113
Figure 11-50	Reset backup card.....	113
Figure 11-51	Clear flash.....	114

Figure 11-52	Force switch.....	114
Figure 11-53	Export configuration files .....	115
Figure 11-54	Import configuration files .....	116
Figure 11-55	Export log files .....	117
Figure 11-56	NE Rename .....	118
Figure 11-57	Batch configure capability.....	119
Figure 11-58	MAC Table .....	120
Figure 11-59	ONU Type and software and hardware versions .....	121
Figure 11-60	Check OLT link status .....	122
Figure 11-61	Slot work state info .....	123
Figure 11-62	RSTP Bridge .....	124
Figure 11-63	RSTP Port info.....	124
Figure 11-64	Reset alarm query condition.....	125
Figure 11-65	Alarm query list.....	126
Figure 11-66	Alarm statistics result.....	126
Figure 11-67	View real time performance.....	127
Figure 11-68	Ping NE .....	128
Figure 11-69	Telnet NE .....	129
Figure 12-1	ONU Detail.....	132
Figure 12-2	NE Rename .....	133
Figure 12-3	ONU Chassis view.....	134
Figure 12-4	ONU Device physical view .....	134
Figure 12-5	move onu .....	135
Figure 12-6	Sync device .....	136
Figure 12-7	ONU Port MAC num limit.....	137
Figure 12-8	RSTP Enable interface .....	137
Figure 12-9	DBA Parameters management interface.....	138
Figure 12-10	Clear ONU performance statistics.....	139
Figure 12-11	ONU reregister.....	140
Figure 12-12	Tips of reregister ONU.....	140

Figure 12-13	Tips of reset ONU .....	140
Figure 12-14	Delete ONU .....	141
Figure 12-15	Tips of delete ONU .....	141
Figure 12-16	Set device linkup.....	142
Figure 12-17	ONU Port MAC table .....	143
Figure 12-18	Device info .....	144
Figure 12-19	FEC Function.....	145
Figure 12-20	Pots port outer test .....	146
Figure 12-21	Pots port inner test.....	147
Figure 12-22	FE Loop Back .....	148
Figure 12-23	Force auto-negotiation.....	149
Figure 12-24	User business configuration .....	150

# 1. Overview

This chapter describes the overall of Network Management System. It mainly includes the following contents:

- Profile
- System structure
- Overall scheme
- Software&Hardware environment

## 1.1. Profile

The Network management system observes FCAPS standard and includes the capability for system management, topology management, equipment management, performance management, fault management, configuration management and so on. It supports real-time monitoring of network equipment and provides reliable safety validation. It optimizes for usability combined the actual application scenarios.

It includes Client, Server and SBI. Client and Server can be deployed separately and also be deployed in the same server.

## 1.2. System structure

- ✧ It is based on J2EE technology and has higher scalability.
- ✧ It includes Client, Server and SBI.
- ✧ Client is a graphic interface program for users operate network management software. You can install multiple sets of clients.
- ✧ Server is a center of back logic processing in network management system. Server gets equipment data from SBI, then store on database. Client gets all information of management by calling server API.
- ✧ SBI is a media between equipments which responsible for equipment interactive. It can be deployed separately with server and also can be deployed on the same server.




Figure 1-1 System structure

### 1.3. Overall scheme




Figure 1-2 General disposition

## 1.4. Software&hardware environment

### **Network management server (include database and SBI)**

CPU: basic frequency above 2GHz

Memory: 2G and above 2G

Disk: 20G disk space

Operating System: Windows2003/Windows XP Pro+SP2/+SP3

JRE: J2SE1.6.0\_01 above

### **Network management server**

CPU: Basic frequency above 2GHz

Memory: 1G and above 1G

Disk: 10G disk space

Video Card: 65000 color, resolving capability 1024\*768 and above

Operating System: Windows2003/Windows XP Pro+SP2/+SP3

JRE: J2SE1.6.0\_01 above

## 2. Quick start

This chapter describes the procedure for starting the Network Management System quickly. It mainly includes the following contents:

- Starting sequence
- Add device
- Set the TRAP server
- Using help

## 2.1. Starting sequence

1. Install Program
  - a. It will generate three programs automatically which are Client, Server and SBI when installation is complete.
2. Starting Server
  - a. Click the server. Listening port of the Server is TCP 5188.
  - b. System will start default database MYSQL and JMS server JORAM automatically in the background.
3. Starting SBI
  - a. Click the SBI. Listening port of the SBI is TCP 5189.
4. Starting Client
  - a. Click the Client, pop-up login window.
5. Login
  - a. Default username and password: root, root
  - b. Default port:5188
  - c. Server IP: IP address of the Server.




Figure 2-1    Login

## 2.2. Add device

### Function

Add network element

### Operating Procedure

1. At primary topological diagram, right-click any of the blanks, pop-up window and select “Add Device” .
2. Input the IP address of the OLT in the pop-up window.
3. Default protocol is SNMP, Read Community: ADSL, Write Community ADSL Port: 161, if it is not, please create a new protocol.
4. After adding device, there will be a device icon in the topological diagram.  
Now, you can operate on this device.




Figure 2-2 Select protocol

## 2.3. Set the Trap Server

### Function

Set the Trap Server

### Operating Procedure

1. In order to receive the alarm information, you must set the Trap Server of the OLT after adding device.
2. Only need set one of the receiving servers as IP address of network management. Choose a OLT, right-click and select “Device Detail”>“Add Default Trap Server” .
3. When your set up is completed, network management system can receive the trap of the device and translate into alarm.

#### **Routine operation**

1. Routine operations operated by clicking the main menu or right button.
2. Click the main menu “Equipment Mgmt”>“NE Query” to inquire OLT or ONU, and then execute “Query”, you can point device quickly, and then do further operation.
3. Input the name of device in the search bar which at the upper right of the main bar, you can also pointing device quickly.

## 3. Main interface

This chapter describes the main interface of the Network Management System. It mainly includes the following contents:

- Main interface
- Main menu
- Main toolbar
- Rolling log output bar
- Status bar

### 3.1. Main interface

After successfully logging, enter the network management interface. The interface is composed by "title bar", "menu bar", "toolbar", "The topological navigation tree", "topology", "the current alarm event" and "rolling log bar" etc. The bottom of the interface is composed by "status bar", "alarm flash tip" and "alarm sound tip".




Figure 3-1 The main interface

### 3.2. Main menu

The main menu includes: System, Equipment Mgmt, Alarm Mgmt, Performance Mgmt, Security Mgmt and Help.




Figure 3-2 The main menu

### 3.3. Main toolbar

Toolbar includes: search box. In the search box you can input the keywords (IP, MAC address or name) to search.



Figure 3-3 The main menu

### 3.4. Rolling log bar

Print the tip, warning and other information of the background . Also can remove the current logging .




Figure 3-4 The rolling log bar

### 3.5. Status bar

The status bar includes state information, alarm light and sound alarm switch.



Figure 3-5 The status bar

Clicking "alarm light" can into the alarm query result dialog.

Clicking "sound alarm switch" can open and close sound alarm.



## 4. System management

This chapter describes system management function of Network Management System. It mainly includes the following contents:

- System management menu
- Lock client
- Modify password
- Data dump
- Db Backup and restore
- Exit

## 4.1. System management menu

### Function

The "System(S)" contains lock client, modify password, data dump, db backup restore and exit.

### Operating Procedure

Click "system(s)" in the main menu, pop-up system management menu list.




Figure 4-1 System management menu

## 4.2. Lock client

### Function

When administrator need to leave the client computer but not wants to shut the client program, he/she can lock the client.

### Operating Procedure

1. Click "system(s)">"Lock Client", pop-up client dialog.
2. Locked, others will not use client .The current user can input password to use when he/she back to the client.




Figure 4-2 Lock client

## 4.3. Modify password

### Function

Modify Password

### Operating Procedure

1. Click "system(s)">"modify password", pop-up modify password dialog.
2. Input old password and the new password in the password box, click "OK".
3. The new password will take effect in the next login.




Figure 4-3 Modify password

## 4.4. Data dump

### Function

Data dump is a program of copy & save data to the tape and another disk .You can set "data type, action, status, start time, file location" in data dump interface .

### Operating Procedure

1. Click "system(s)">"data dump", pop-up data dump interface.
2. Choose "action, status, start time, file location", click "OK" .




Figure 4-4 Data dump

## 4.5. Db Backup and restore

### Function

User can restore previous backup database documents by "Db backup and restore".

### Operating Procedure

1. Click "system(s)">"Db Backup And Restore", pop-up Db Backup And

- Restore dialog.
2. Choose the database file which you need to restore, click "recovery". After restore successfully, the server must restart.




Figure 4-5 Db backup and restore

## 4.6. Exit

### Function

Exit the network management system.

### Operating Procedure

1. Click "system(s)">"exit", pop-up exit dialog..
2. Click "Yes" to exit.




Figure 4-6 Exit

## 5. Equipment management

This chapter describes equipment management function of Network Management System. It mainly includes the following contents:

- NE query
- Scan IPC
- Review IPC

## 5.1. Equipment management menu

### Function

The main menu (Equipment Mgmt. (D)) contains "NE query, scan IPC and review IPC".

### Operating Procedure

Click "Equipment Mgmt. (D)" in the main menu pop-up equipment management menu list.




Figure 5-1 Equipment management menu

## 5.2. NE query

### Function

Input corresponding query condition, query NE (network element).

### Operating Procedure

1. Click "Equipment Mgmt. (D)">"NE Query", pop-up NE Query dialog.
2. You can look for NE according to domain, group, equipment type, name and the information of users.
3. Network elements are displayed through list .A serial of operation by right-click in the table.




Figure 5-2 NE Query

### 5.3. Scan IPC

#### Function

Scan existing IPC in a certain range.

#### Operating Procedure

1. Click "Equipment Mgmt(D)">"Scan IPC", pop-up scan IPC dialog.
2. Input IP range; scan all IPC within this range.




Figure 5-3 Scan IPC

## 5.4. Review IPC

### Function

Review IPC

### Operating Procedure

1. Click "Equipment Mgmt(D)">"Review IPC", pop-up review IPC dialog.




Figure 5-4 Review IPC

## 6. Alarm management

This chapter describes the alarm and event processing. It mainly includes the following contents:

- Alarm management menu
- Alarm and Event query
- Alarm process rule
- Alarm sound
- Email notify configure
- Alarm parameter configuration

## 6.1. Alarm management menu

### Function

The main menu "alarm management" contains alarm management function which are alarm and event query, alarm process rule, alarm sound, email notify parameter configuration and alarm parameter configuration.

### Operating Procedure

Click the main menu "alarm management ", view the alarm management menu.




Figure 6-1 Alarm management menu

## 6.2. Alarm and event query

### Function

Query alarm event, current alarm and history alarm.

### Operating Procedure

1. Click the main menu "Alarm management >"Alarm and Event query", pop-up the alarm and event query dialog.
2. User can input multiple combinations of conditions to query alarm or event.

**NOTE:**

In order to receive the alarm or event of the OLT, you must set the IP of network management server in the TRAP server list.






Figure 6-2 Query alarm or event

3. After input conditions, click “query” to go to the alarm query result window.
  4. Show matching alarm records by list.
  5. Click button or right-click menu to deal with alarm, for example comfirm
- Alarm as below.



6. It can also show matching alarm records by pie chart as below.



## 6.3. Alarm process rule

### Function

Configure alarm process rule. Alarm process rule include: alarm automatic clear, alarm automatic acknowledge, alarm shield and email send rule.

### Operating Procedure

1. Click the main menu “Alarm management >”Alarm process rule”, pop-up the alarm rule window.




Figure 6-3 Alarm rule

2. User can add, modify and delete alarm rule. The server is effective immediately after applying rules.

## 6.4. Alarm sound

### Function

Configure alarm sound.

### Operating Procedure

1. Click the main menu “Alarm management >”Alarm Sound”, pop-up the alarm sound configuration window.
2. Set the duration of alarm sound and every alarm level’s sound file.




Figure 6-4 Alarm sound

## 6.5. Email notify configure

### Function

Configure Email.

### Operating Procedure

Click the main menu “Alarm management >”Email Notify Config”, pop-up the email notify configuration window. Configure the SMTP server parameter, queue parameter.




Figure 6-5 Email notify config

## 6.6. Alarm parameter configuration

### Function

Configure alarm parameter, such as total alarm count, synchronous poll interval and link status interval.

### Operating Procedure

Click the main menu “Alarm management “>”alarm parameter configuration”, pop-up the alarm parameter configuration window. Enter parameter’s value, click “OK”.




Figure 6-6 Alarm parameter configuration

## 7. Performance management

This chapter describes performance management function of Network Management System. It mainly includes the following contents:

- Performance management menu
- Performance running configuration
- Performance collect task management
- Performance task data query

## 7.1. Performance management menu

### Function

The main menu (Performance Mgmt (P)) contains "performance running configuration, performance collect task management, performance task data query".

### Operating Procedure

Click "Performance Mgmt (P)" in the main menu pop-up performance management menu.




Figure 7-1 Performance management

## 7.2. Performance running configuration

### Function

Set real-time performance task and history performance task running parameter.

### Operating Procedure

1. Click "Performance Mgmt (P)">"performance running configuration(s)",  
Pop-up performance running configuration interface.




Figure 7-2 Performance running configuration

### 7.3. Performance collect task management

#### Function

Set task name, start time, end time, granularity, collect task performance.

#### Operating Procedure

1. Click "Performance Mgmt (P)">"performance collect task management ",  
Pop up performance collect task management interface.
2. Set collect condition, click "Query".




Figure 7-3 Performance task management

## 7.4. Performance task data query

### Function

Query performance task result.

### Operating Procedure

1. Click "Performance Mgmt (P)">"performance task data query ", Pop up performance task data query interface.
2. Set collect condition, click "Query", you will see the result.




Figure 7-4 Performance task result query



## 8. Security management

This chapter describes security management function of Network Management System. It mainly includes the following contents:

- Security management menu
- User management
- Role management
- Permission management
- Online user
- Operation log

## 8.1. Security management menu

### Function

The main menu (Security Mgmt(S)) contains "user mgmt, role mgmt, permission mgmt (A),online user(A),operation Log".

### Operating Procedure

Click "Security Mgmt(S)" in the main menu pop-up security management menu list.




Figure 8-1 Security mgmt(S)

## 8.2. User management

### Function

Manage user

### Operating Procedure

1. Click "Security Mgmt(S)">"user mgmt ", pop-up user management interface.
2. It supports create, modify, delete, prohibit and prohibit(R).




Figure 8-2 Create user

- ✧ User management is very important in security management.  
Unauthenticated user is not able to use network management system.
- ✧ User information includes basic attributes, user active, valid settings, attachment attributes and selection role.

**Instruction:**

System default user is root, default password is root. Root has the maximum permission.

- ✧ Create and modify: set user basic attribute, role and selection manage scope (users have a root domain. All sub domains; group and network

element of root domain is visible).

- ✧ Delete: Built-in user and logged user can not be deleted.
- ✧ Prohibit: This operation will forbid selected user. The forbidden user will not log on to network management system.
- ✧ Prohibit(R): The forbidden user will back to normal.

## 8.3. Role management

### Function

Role management is used for assigning right.

### Operating Procedure

1. Click "Security Mgmt(S)">"role mgmt ",pop-up role management interface.
2. It supports create, modify and delete role.




Figure 8-3 Role management

This system has 4 built-in roles:

- ✧ Administrator: It has maximum permission.

- ✧ Operator: Regular configuration.
- ✧ Monitor: Monitor role.
- ✧ Maintainer: Maintainer role..

It can assign permission to the role.

Built-in role can not be deleted.

## 8.4. Permission management

### Function

Manage permission

### Operating Procedure

1. Click "Security Mgmt(S)">"permission mgmt ", pop-up permission management interface.
2. It supports create, modify and delete permission.




Figure 8-4 Permission management

This system has 2 built-in permissions:

- ✧ ALL: Include all permission.
- ✧ BASE: Minimum permission.

Built-in permission can not be deleted.

## 8.5. Online user

### Function

Look over online user.

### Operating Procedure

1. Click "Security Mgmt(S)">"online user(A) ",pop-up online user interface.




Figure 8-5 Online user

## 8.6. Operation log

### Function

Look back operation log.

### Operating Procedure

1. Click "Security Mgmt(S)">"operation log ", pop-up operation log interface.




Figure 8-6 Operation log



## 9. Topology management

This chapter describes topology management function of Network Management System. It mainly includes the following contents:

- Topology map operation
- Topology toolbar
- Auto layout
- Change name
- Search and locate
- Save position
- Domain and group management
- Device scan
- Add devices
- Physical topology map

## 9.1. Topology map operation

### Function

Topology map provides rich ways to display equipments, which is the entrance of operation and configuration.

It provides logic topology map and physical topology map.

Logic topo map: Grouped based on the geographical location of network equipment.

Physical topo map: display by physical connection mode "OLT-ODN-ONU".

### Operating Procedure

The operation of topology map can be invoked by right-click menu or topological toolbar.

## 9.2. Topology toolbar



Figure 9-1 Toolbar

Topology toolbar located in the right of main interface. When the mouse moves to button, it will display corresponding function's tip.

## 9.3. Auto layout

### Function

It provides auto arrange for the position of network element, domain and group.

### Operating Procedure

1. Enter domain topology map, right click pop-up the menu.
2. Select "auto layout">>"circular layout/tree layout/right side layout".
3. Recommend using "right side layout".




Figure 9-2 Auto layout

## 9.4. Change name

### Function

The default display name is EMS name, but sometimes other name need to displayed.

### Operating Procedure

1. Enter domain topology map, right click pop-up the menu.
2. Select "change name">>"IP address/MAC address/EMS name/simple name/device name", you can choose it according you need.
  - ✧ EMS name: the description information of device.
  - ✧ Simple name: ONU number.
  - ✧ Device name: It is a internal identifying information and is used to debug.




Figure 9-3 Change name

## 9.5. Search and locate

### Function

Search and locate device

### Operating Procedure

1. There is a search box in the top right corner of main interface. User can input EMS, IP, MAC information etc. click "search".
2. System support partial matching search.



Figure 9-4 Search device

## 9.6. Save position

### Function

Save network element, domain and group position.

### Operating Procedure

1. Enter domain topology map, right click pop-up the menu.
2. Select and click "save position" can save current topology map position.

When you enter topology map next time, the elements will be displayed at

the position last saved.

## 9.7. Domain and group management

### Function

In order to display network element in different areas, network management system group network element into domain and group.

Domain: It contains domain, network element, group and nests sub-domain unlimited.

Group : It only contains network elements, can not be nested.

### Operating Procedure

1. Enter domain topology map, right click pop-up the menu.
2. Click "create domain", pop-up create sub domain interface.




Figure 9-5 Create domain

- ✧ User inputs display name, selects "Bg color" and "Bg image".
- ✧ It can create and modify group.

## 9.8. Device scan

### Function

Scan devices

### Operating Procedure

1. Enter domain topology map, right click pop-up the menu.
2. Click "scan devices", pop-up scan devices interface.
3. Input start IP, end IP, device type then click "start to scan".




Figure 9-6 Scan devices

## 9.9. Add devices

### Function

Add devices

### Operating Procedure

1. Enter domain topology map, right click pop-up the menu.
2. Click "add devices" pop-up add devices interface.
3. Input IP address and communication parameter, and then click "OK".




Figure 9-7 Add devices

## 9.10. Physical topology map

### Function

Physical topology map displayed the connection of "OLT-ODN-ONU".

### Operating Procedure

1. Enter domain topology map, select "OLT" then click "Physical topology map", pop-up Physical topology map interface.




Figure 9-8 Physical topology map

## 10. OLT detail

This chapter describes the detail of the OLT .It mainly includes the following contents:

- OLT basic information
- Card List
- ONU List
- Invalid ONU List
- ONU Auth Mode
- MAC White List
- LOID White List
- MAC Bind
- ONU Replace

## 10.1. OLT basic information

### Function

The device management console is the entrance of basic information and configuration, including basic information and basic operation of network element, card and port.

### Operating Procedure

1. Select a OLT, click right-menu "Device Detail", pop-up device detail window.




Figure 10-1 Device detail

- ✧ NE Basic Info: include basic information, TRAP servers list and In-band network management parameter.
- ✧ Card List: The slot, type, version and state of the card.
- ✧ ONU List: Authorized ONU list
- ✧ Invalid List: Unauthorized ONU list
- ✧ ONU Auth Mode: The authentication mode of ONU.
- ✧ MAC White List: MAC and LOID white list
- ✧ MAC Bind: Binding MAC and LOID. Only to match MAC and LOID, then the

ONU can be on-line.

- ❖ ONU Replace: Replace the old ONU with the new.

## 10.2. Card list

### 10.2.1. Provision card

#### Function

Add card into the card list.

#### Operating Procedure

1. Select a OLT, right-click menu "device detail", pop-up device detail window.
2. Select the card list tab; you will see all card lists.
3. Click "provision", pop-up provision card window.
4. Select slot and card type, there will be some notice information after click "OK".




Figure 10-2 Provision card

## 10.2.2. Delete card

### Function

Delete card from the network management system.

### Operating Procedure

1. Select an OLT, right-click menu "device detail", pop-up device detail window.
2. Select the card list tab; you will see all card lists.
3. Select one card, click "delete card" pop-up the delete card interface.




Figure 10-3 Delete card



### CAUTION:

Delete card results in card and its configuration data lost.

---

## 10.2.3. Reset card

### Function

Reset card can reset the card of the OLT.

### Operating Procedure

1. Ditto "provision card", in the card list window, select one card, click "reset card", pop-up the reset card interface.



Figure 10-4 Reset card

**CAUTION:**

Card reset will result in the existing configuration data on the card is lost. Handle with care!

### 10.3. ONU list

#### Function

Manage and control device by authorization.

#### Operating Procedure

1. Select a OLT, right-click "device detail", pop-up the device detail window.
2. Select a PON card in the left navigation tree, click the tab "ONU List", show all ONU of the PON card.
3. The ONU list displays all ONUs which are authorized as below:




Figure 10-5 ONU List

### 10.3.1. Authorize ONU

#### Function

Manual authorize ONU

#### Operating Procedure

- Fill in the parameter of the ONU authorization, manual authorize ONU. The system will list the current available ONU authorization number automatically to choose from.




Figure 10-6 Add ONU

- The results of the authorization will real-time display in the message box. System will synchronize configuration of the ONU which is authorized successfully.

```
[System Message] 2012-03-12,10:11:00,+0800 Start Synchronize Task (192.168.3.29-12/02:35)
[System Message] 2012-03-12,10:11:00,+0800 Read 192.168.3.29-12/02:35 Onu General Porerty
[System Message] 2012-03-12,10:11:00,+0800 Read 192.168.3.29-12/02:35 Onu General Porerty success
[System Message] 2012-03-12,10:11:00,+0800 Read 192.168.3.29-12/02:35 ONU Slot Information
[System Message] 2012-03-12,10:11:00,+0800 Read 192.168.3.29-12/02:35 ONU Slot Information success
[System Message] 2012-03-12,10:11:00,+0800 Read 192.168.3.29-12/02:35 ONU Card Information
[System Message] 2012-03-12,10:11:00,+0800 Read 192.168.3.29-12/02:35 ONU Card Information success
```

Figure 10-7 Successful authorization message

3. If the authorization is fail, the causes also will real-time display in the message box.

```
[System Message] 2012-03-12,10:10:33 ONU_ADD 12/02:36 44-59-04-00-96-7D fail
Exception: the mac of onu has been authorized:SLOT=13 AuthNo=35
```

Figure 10-8 Failed Authorization fault message

### 10.3.2. Delete ONU

#### Function

Delete ONU.

#### Operating Procedure

1. Select one or more authorized ONUs; click "Delete ONU" as below.




Figure 10-9 Delete ONU

2. The results of the deleting ONU will real-time display in the message box. Network management System will delete ONU and real-time update in the topological diagram.

```
[System Message] 2012-03-12,09:51:34 ONU_DELETE 12/02:35 44-59-04-00-96-7D success
```

Figure 10-10 Delete successful message

### 10.3.3. Reset ONU

#### Function

Reset ONU.

#### Operating Procedure

1. Select one or more ONU, click "Reset ONU" ,the result will real-time display in the message box as below.

[System Message] 2012-03-12,11:32:24 ONU\_RESET 192.168.3.29-12/02:34 success

Figure 10-11 Reset ONU

### 10.3.4. Register ONU

#### Function

Register ONU.

#### Operating Procedure

1. Select one or more ONU, click "Register ONU" , the result will real-time display in the message box as below.

[System Message] 2012-03-12,11:33:20 ONU\_REGISTER 192.168.3.29-12/02:34 success

Figure 10-12 Register ONU

## 10.4. Invalid ONU list

#### Function

View invalid ONU.

#### Operating Procedure

1. Invalid ONU list display all of the ONU which are unauthorized. Select one PON card in the left navigation tree; click the tab "Invalid ONU List" as below.




Figure 10-13 Invalid ONU list

## 10.5. Batch authorize ONU

### Function

Batch authorize ONUs.

### Operating Procedure

1. Select one or more ONUs in the invalid ONU list, and select authorization numbers, batch issued to the device. The device will authorize ONU after issue to the device.




Figure 10-14 Batch authorize

## 10.6. ONU authorization Mode

### Function

Select ONU authorization mode.

### Operating Procedure

1. Configure authorization strategy and mode of each card.
2. Authorization strategy includes MAC, LOID, MAC+LOID and NONE.
3. Auto Authorization Mode includes Auto-Manual, Auto and Manual.




Figure 10-15 ONU authorized mode

## 10.7. MAC white list

### Function

View the MAC White List.

### Operating Procedure

1. Add new item to MAC White List: Click "Add ", fill in the number.




Figure 10-16 Add white list

2. Batch modifies MAC: Select the MAC you want to change, click Batch Modify. For example, MAC address begin with "44-59-04", end in "00", 44-59-04-00-01-00 begin to circulate and can be used in card 1.




Figure 10-17 Batch Modify

3. You will see the MAC address batch modified. And you can also modify MAC in the table.




Figure 10-18 MAC white list

4. Delete: Select rows of the table, click delete button.

## 10.8. LOID white list

### Function

View the LOID White List.

### Operating Procedure

1. Add new entry to LOID White List: Click "Add ", fill in the number.




Figure 10-19 Add LOID white

2. Batch modify LOID+PASSWORD: Select the rows of the table, click "Batch Modify". For example, LOID begin with SN2010, end in 01. PASSWORD begin with PSW, 001 begin to circulate and can be used in 01/01 Port as below.

**Batch Modify**

LOID

**LOID**

Modify LOID

Pre:	SN2010	Suf:	01
Start:	1	Count:	5
Length:	1	Interval:	4

**Password**

Modify Pass...

Pre:	PSW	Suf:	
Start:	1	Count:	5
Length:	3	Interval:	1

**MAC**

Modify MAC

Pre:		Suf:	
Start:		Count:	
Interval:			

**Auth Range**

Auth Type: Slot Auth Location: 01

**OK** **Cancel**

Figure 10-20 LOID Batch modify

3. You will see the LOID+PASSWORD batch modified. And you can also modify LOID and PASSWORD in the table.

NE Basic Info | Card List | ONU List | Invalid ONU list | ONU Auth Mode | MAC White List | LOID White List | MAC Bind | ONU Replace |

LOID White List

Auth Location	LOID	Password
Slot1	SN2010101	PSW001
Slot1	SN2010201	PSW002
Slot1	SN2010301	PSW003
Slot1	SN2010401	PSW004
Slot1	SN2010501	PSW005

Figure 10-21 LOID White list

4. Delete: Select rows of the table, click delete button.

## 10.9. MAC bind

### Function

Bind MAC address

### Operating Procedure

1. Add new MAC Binding: Fill in the MAC address and LOID, and then click “OK” .




Figure 10-22 MAC-LOID Bind

2. Delete: Select the rows, click delete button.

## 10.10. ONU replace

### Function

Replace ONU

## Operating Procedure

- Select "ONU Replace" tab in the main menu, fill in the old MAC and the new MAC.




Figure 10-23 ONU Replace

- Apply: Manual editing or delete rows of the table, click "Apply". Operator should pay attention to items related to the operation. For example, the ONU which replace MAC must be existed and MAC addresses be replaced cannot be same etc




Figure 10-24 Replace fault

# 11. OLT management

This chapter describes the function of OLT management. It mainly includes the following contents:

- Delete device
- View management(O)
- Modify NE discover parameter
- Sync mgmt(S)
- Configuration(S)
- Control command(C)
- Operation(O)
- State callbacks
- View current alarm
- View history alarm
- View immediate performance
- View real time performance
- Ping NE
- Telnet NE

## 11.1. Delete device

### Function

Delete needless NE in topology map.

### Operating Procedure

1. Select NE which you want to delete, right click "delete devices".
2. Click "OK", the NE will be deleted.




Figure 11-1 Delete devices

## 11.2. View management

### 11.2.1. Chassis view

#### Function

Chassis view can express card, port and status truly.

#### Operating Procedure

1. Right click OLT, select "view management (O)">"chassis view" pop-up chassis view interface.
2. There are three areas, object navigation tree, chassis view, properties.
  - ✧ Object navigation tree: Card and port management are displayed in the top left. When select object on the left side three, on the right side chassis view will also be selected.
  - ✧ Chassis view: A graphic to display position and status. The top is toolbar.
  - ✧ Properties: The basic information of object.

**NOTE:**

Double click can open chassis view.




Figure 11-2 Chassis view

## 11.2.2. Devices physical map

### Function

Physical topology map displayed the connection of "OLT-ODN-ONU"

### Operating Procedure

1. Right click OLT, select "view management (O)">"devices physical map" pop-up devices physical map interface.




Figure 11-3 Devices physical map

### 11.2.3. Move

#### Function

Move NE, group and domain to another domain or group.

#### Operating Procedure

1. Right click OLT, select "view management (O)">"move to "pop-up "move....." interface.
2. Select new destination domain or group from left tree.




Figure 11-4 Move....

## 11.3. Sync management

### 11.3.1. Sync device

#### Function

Sync device ensure device configuration consistent with network management system configuration .When device configuration change, you can manual sync to ensure the information consistent.

#### Operating Procedure

1. Right click OLT, select "sync mgmt(S)">"sync device", it will launch

- synchronous task.
2. Background sync information will be printed in rolling log column during sync.  
Once has error messages, it can find problem immediately.
  3. It has whirling progress message in the top right corner of device during sync.




Figure 11-5 Device sync

4. If fail, it will has "!" to message in top right corner of device.

### 11.3.2. Alarm sync

#### Function

Alarm sync can promise show alarm message timely.

#### Operating Procedure

1. Right click OLT, select "sync mgmt(S)">"alarm sync".
2. If it has alarm now, alarm message will be displayed.

Realtime Alarm List						
Severity	ProbableCause	Source	Type	State	Update Time	Source Type
Major Alarm	Config have not saved	192.168.3.29-07	Equipment Alarm	not acked and not cleared	2012-03-07 14:26:15	SWA

Figure 11-6 Alarm message

### 11.3.3. Category sync

#### Function

Category sync is division synchronization each property parameter.

#### Operating Procedure

1. Right click OLT, select "sync mgmt(S)">"category sync".
2. Select one or more property parameters which need to synchronization, click "start (B)".




Figure 11-7 Category sync

## 11.4. Configuration

### 11.4.1. Uplink configure

#### 11.4.1.1. Uplink port configure

##### Function

Configure uplink port parameter.

##### Operating Procedure

1. Right click OLT, select "configuration(C)">"uplink config(U) ">"uplink port

- config" enter port list interface.
2. Set admin state, port type, auto neg, FC, MAC learning, priority state and priority.
  3. Click "Apply(C)"pop-up progress bar.
  4. Click "Refresh" to look up current port configuration.




Figure 11-8 Uplink port config

### 11.4.1.2. RSTP enable

#### Function

Opening or closing RSTP

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"uplink config (U)">"RSTP Enable" enter RSTP enable interface.
2. Select disable or enable in RSTP Switch column.




Figure 11-9 RSTP Enable

### 11.4.1.3. Port RSTP

#### Function

Port RSTP config

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"uplink config (U)">"Port RSTP" enter port RSTP configuration interface.
2. Set port priority and port path cost. But keep in mind, you must ensure RSTP enable before the set.




Figure 11-10 Port RSTP config

#### 11.4.1.4. Trunk port link aggregation

##### Function

Configure trunk

##### Operating Procedure

1. Right click OLT, select "configuration(C)">"uplink config (U)">"trunk port link aggregation" enter config interface.
2. Click "add" to add a new trunk item and select this item.
3. Choose host port and member port from right windows.
4. Click "Apply(S)" save configuration.
5. Select a item, click "delete" can delete nuisance item.
6. You also can modify host port and member port.




Figure 11-11 Trunk port link aggregation

## 11.4.2. PON isolate

### Function

PON isolate is that the ports of the same PON card can not communicate with each other.

### Operating Procedure

1. Right click OLT, select "configuration(C)">"PON isolate "enter PON port isolate config interface.
2. Select Slot NO, select enable status.




Figure 11-12 PON port isolate

### 11.4.3. IGMP

#### Function

Configure global parameter and auth.

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"IGMP ">enter IGMP config interface.
2. Set IGMP protocol (PROXY, SNOOPING, DISABLE), Proxy IP and IGMP VLAN.




Figure 11-13 Global property

3. Select "IGMP Auth template", add a template and add IP, click "Apply".




Figure 11-14 IGMP Auth template

4. Select "FE Auth template", click "add" can add FE port, choose template name.




Figure 11-15 FE Auth template

5. Select "Group config", you can set vlan, leave delay and uplink vlan in this interface.




Figure 11-16 Group config

6. Select "Prejoin", set IP.




Figure 11-17 Prejoin

7. Select "cascade port", set cascade enable/disable.




Figure 11-18 Cascade port

8. Select "ONU Fast leave", set fast leave enable/disable.




Figure 11-19 ONU Fast leave

## 11.4.4. QOS management

### Function

QOS management includes QOS template management, QOS template bind/unbind, packets rate control, ONU bandwidth and QOS priority.

### Operating Procedure

1. Right click OLT, select "configuration(C)">"QOS management "enter QOS config interface.
2. Click "add" create QOS Template, input template name, VLAN ID, source IP, source IP Mask, Dest IP, Dest IP mask, source mac, Dest mac, priority, Ethernet type, protocol type, TCP/UDP SRC port, TCP/UDP DES port, TOS,CMD, rate limit, queue, tos value, flow port, new port and new port tag. Click "OK", create successfully.




Figure 11-20 Create QOS Template

3. Click "QOS Template bind/unbind" in top option. Select destination port and QOS template from left tree and right QOS template list. Click "save", bind the port to the QOS template.




Figure 11-21 QOS Template bind/unbind

4. Click "packets rate control" in top option, set each packet state and speed.




Figure 11-22 Packets rate control

5. Click "ONU Bandwidth" in top option, set its up stream bandwidth, down stream bandwidth, up stream assured and up stream fixed bandwidth.




Figure 11-23 ONU Bandwidth

6. Click "QOS priority" in top option, choose QOS priority mode from weight, strict and rotate.




Figure 11-24 QOS priority

### 11.4.5. MAC management

#### Function

MAC management

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"MAC Management ">enter MAC management interface.
2. Set aging time 0~300s.
3. Click "ONU Port MAC Number Limit", set MAC limit.




Figure 11-25 MAC Management




Figure 11-26 ONU Port mac number limit

**CAUTION:**

Set aging time to zero which should be caution with .Otherwise the business of ONU will not self-healing after cyclization remove.

#### 11.4.6. Smart grid Server config

##### Function

Smart grid server config includes smart grid server name, connect IP and

connect port.

### Operating Procedure

1. Right click OLT, select "configuration(C)">"Smart Grid Server Config" enter configuration interface.
2. Click "add", add a new item, input smart grid server name, connect IP and connect port. Click "Apply to Equipment (U)", the configuration is completed.
3. Select some Connect ID, click "Delete" can delete the item.
4. Click "Refresh", look up current configuration.




Figure 11-27 Smart grid server config

### 11.4.7. EMS access control

#### Function

Control network management access rights.

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"EMS access control" enter config interface.

2. Click "add", add a new item, input EMS IP, Network Mask and Enable.
3. Click "apply", configuration completed.




Figure 11-28 EMS Access control

### 11.4.8. Performance statistic switch

#### Function

Set performance statistic switch of OLT cards and ONU.

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"performance statistic switch" enter performance statistic switch management interface.
2. Set OLT cards statistic switch enable.
3. Click "ONU port statistic switch", set enable.
4. Click "save", save configuration.




Figure 11-29 Card port statistic switch




Figure 11-30 ONU Port statistic switch

### 11.4.9. Optical detect switch

#### Function

Optical detect enabled.

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"optical detect switch" enter optical detect switch management interface.
2. Choose "enable" in enable status list.
3. Click "save", save configuration.




Figure 11-31 Optical detect switch

### 11.4.10. Alarm threshold management

#### Function

Set alarm threshold .If reached threshold, system will make alarms.

## Operating Procedure

1. Right click OLT, select "configuration(C)">"alarm threshold management" enter alarm threshold management interface.
2. In the interface, you can set the CPU usage threshold, the uplink port, ONU optical module and ONU FE port threshold. However, if you should set to ONU FE port, you must be open the switch in the ONU performance.
3. Click "save", save configuration.




Figure 11-32 CPU usage threshold




Figure 11-33 Uplink port threshold




Figure 11-34 ONU Optical module threshold

## 11.4.11. Alarm template management

### Function

Create alarm template and binding/unbinding ports.

### Operating Procedure

1. Right click OLT, select "configuration(C)">"alarm template management" enter alarm template management interface.
2. Click "add", add a alarm template. Set template name, object layer, object type, alarm code, alarm enable, report threshold and clear threshold.
3. Select a template, click "edit" can modify this template, click "delete" can delete this template, click "refresh" look for current alarm template.
4. Click "template bind/unbind" enter port bind interface.
5. Select port to bind, click "apply to equipment".




Figure 11-35 Template management




Figure 11-36 Template bind/unbind

### 11.4.12. Outer VLAN

#### Function

Configure outer VLAN

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"Outer Vlan" enter outer vlan board configuration interface.
2. Click "add", add a group data.
3. Click "business type"; choose business type from pull-down box.
4. Double-click "business name", input name in the box.
5. Double-click "start vlan", input start vlan ID in the box.
6. Double-click "end vlan", input end vlan ID in the box. End vlan is equal or greater than start vlan. If the starting and ending vlan is different, so must for TAG.

7. Click "uplink port or trunk group", choose uplink port or trunk group from pull-down box.
8. Click "TAG/UNTAG", choose tag/untag from pull-down box.
9. Click "save", save configuration.
10. Select a group data, click "delete", and delete this group data.




Figure 11-37 Outer vlan

### 11.4.13. QINQ template

#### Function

Create QINQ template

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"QINQ template" enter QINQ template configuration interface.
2. Click "add", create a QINQ template, input template name, business name,

svlan ID, svlan TPID and svlan COS. Click "...create rule domain type, set rule type, operator and rule domain value.

3. Click "apply", the template will be sent to equipment.
4. Select a template, click "delete", and delete this template.




Figure 11-38 Create QINQ template

#### 11.4.14. QINQ profile binding

##### Function

Bind QINQ profile to ports.

##### Operating Procedure

1. Right click OLT, select "configuration(C)">"QINQ profile binding "enter QINQ profile binding interface.
2. Choose profile name and ports, click "apply".
3. Select a profile; click "clear" can clear it.




Figure 11-39 QINQ Profile binding

### 11.4.15. System ONU ACL function

#### Function

Configure the FE port ACL rules.

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"system ONU ACL function "enter system ONU ACL function interface.
2. Choose rule action and create rule domain type.
3. Click "add/delete", add/delete ACL rule.




Figure 11-40 System ONU ACL function

### 11.4.16. Template configuration

#### Function

Configure all kinds of template.

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"Template configuration "enter template configuration interface.
2. Select object which you need to create template in the left tree content filter.
3. You can click "Add, Refresh, Delete, Apply" button to create, modify, delete, view template.




Figure 11-41 Template configuration

### 11.4.17. PON-Uplink bind

#### Function

Bind PON-uplink

#### Operating Procedure

1. Right click OLT, select "configuration(C)">"PON-Uplink Bind "enter PON-Uplink Bind interface.
2. Click "add", add a new item.
3. Select uplink port and PON in pull-down box.
4. Click "apply", save configuration.




Figure 11-42 PON-Uplink Bind

## 11.5. Control command

### 11.5.1. Upgrade system software

#### Function

Upgrade system software

#### Operating Procedure

1. Right click OLT, select "Control Command(C)">"Upgrade system software" "enter Upgrade system software interface.
2. Click "Down File type", select "Down File type" in pull-down box.

3. Click "slot no", select slot no in pull-down box.
4. Input FTP server IP in FTP server IP box.
5. Input FTP user name in user name box.
6. Input FTP password in password box.
7. Input file name in file name box.
8. Before upgrade ,running ftp server and configuring its user name, password and home directory.




Figure 11-43 Upgrade system software

### 11.5.2. Backup software

#### Function

Backup system software

### Operating Procedure

1. Right click OLT, select "Control Command(C)">"backup software "enter backup software interface.
2. Input FTP server IP in FTP server IP box.
3. Input FTP user name in user name box.
4. Input FTP password in password box.
5. Input file name in file name box.
6. Click "backup", backup system software.
7. Before backup, running ftp server and configuring its user name, password and home directory.




Figure 11-44 Backup system software

### 11.5.3. Batch upgrade ONU

#### Function

Batch upgrade ONU

#### Operating Procedure

1. Right click OLT, select "Control Command(C)">"batch upgrade ONU "enter batch upgrade ONU interface.
2. Input FTP server IP in FTP server IP box.
3. Input FTP user name in user name box.
4. Input FTP password in password box.
5. Input file name in file name box.
6. Choose "slot no" in pull-down box.
7. Check one or several ONU in left bottom tree.
8. Click "upgrade", upgrade ONU software.
9. Before upgrade, running ftp server and configuring its user name, password and home directory.




Figure 11-45 Batch upgrade ONU

### 11.5.4. IGMP management

#### Function

Flush IGMP configuration.

#### Operating Procedure

1. Right click OLT, select "Control Command(C)">"IGMP management ">"flush IGMP configuration" pop-up flush IGMP configuration interface.
2. Click "OK" or "cancel".




Figure 11-46 Flush IGMP configuration

## 11.6. Operation

### 11.6.1. Save device config

#### Function

Save current configuration

#### Operating Procedure

1. Right click OLT, select "Operation (O)">"save device config "pop-up save device interface.
2. Click "Yes", save current configuration.



Figure 11-47 Save current configuration

### 11.6.2. Sync device time

#### Function

Sync device time

#### Operating Procedure

1. Right click OLT, select "Operation (O)">"sync device time "pop-up update time interface.
2. Click "Yes", update time. The effect can be verified by the time of the equipment real time information.




Figure 11-48 Update time

### 11.6.3. Restart

#### Function

Restart device

#### Operating Procedure

1. Right click OLT, select "Operation (O)">"restart" pop-up the tip interface of restart.
2. Click "Yes", restart device.




Figure 11-49 Restart device

### 11.6.4. Reset backup card

#### Function

Reset backup card

#### Operating Procedure

1. Right click OLT, select "Operation (O)">"reset backup card" pop-up the tip interface of reset backup unit.
2. Click "Yes", reset backup unit.




Figure 11-50 Reset backup card

### 11.6.5. Clear flash

#### Function

Clear flash

#### Operating Procedure

1. Right click OLT, select "Operation (O)">"clear flash" pop-up the tip interface of clear flash.
2. Click "Yes", clear flash.




Figure 11-51 Clear flash

### 11.6.6. Force switch

#### Function

Force switch

#### Operating Procedure

1. Right click OLT, select "Operation (O)">"force switch" pop-up the tip interface of force switch.
2. The switch interval must be more than two minutes.
3. Click "Yes", force switch.




Figure 11-52 Force switch

### 11.6.7. Export configuration files

#### Function

Export configuration files.

#### Operating Procedure

1. Right click OLT, select "Operation (O)">"export configuration files" pop-up export configuration files interface.
2. Input FTP Server IP, user name, password and file name.
3. Click "export configuration files", pop-up the tip of success.




Figure 11-53 Export configuration files

## 11.6.8. Import configuration files

### Function

Import configuration files.

### Operating Procedure

1. Right click OLT, select "Operation (O)">"import configuration files "pop-up import configuration files interface.
2. Input FTP Server IP, user name, password and file name.
3. Click "import configuration files", pop-up the tip of success.




Figure 11-54 Import configuration files

### 11.6.9. Export log files

#### Function

Export log files.

#### Operating Procedure

1. Right click OLT, select "Operation (O)">"export log files" pop-up export log files interface.
2. Input FTP Server IP, user name, password, slot NO and file name.
3. Click "export log files", pop-up the tip of success.




Figure 11-55 Export log files

## 11.6.10. NE rename

### Function

Network elements rename

### Operating Procedure

1. Right click OLT, select "Operation (O)">"NE rename" pop-up input name interface.
2. Input new name, click "OK".




Figure 11-56 NE Rename

## 11.7. State Callbacks

### 11.7.1. Open Batch Configure Capability

#### Function

Introduce batch configure capability.

#### Operating Procedure

1. Right click OLT, select "State Callbacks">" open batch configure capability".  
View batch command and template.




Figure 11-57 Batch configure capability

### 11.7.2. MAC table

#### Function

View ONU MAC table

#### Operating Procedure

1. Right click OLT, select "State Callbacks">>"MAC table".
2. Select slot No, view MAC table and VLAN ID.

The screenshot shows a software interface titled "MAC Table". On the left, there is a tree view under the IP address "192.168.3.223" with nodes: Slot:04(EP4), Slot:06(HUP), Slot:09(HUP), and Slot:14(EP4). On the right, a table displays MAC table entries:

ID	Slot No	MAC	VLAN ID
1	14	00-00-00-66-66-66	4088
2	14	00-1D-2B-02-AD-F0	2000

A "Cancel" button is located at the bottom right of the table area.

Figure 11-58 MAC Table

### 11.7.3. ONU type and software and hardware versions

#### Function

View ONU type and software and hardware versions.

#### Operating Procedure

1. Right click OLT, select "State Callbacks">>"ONU type and software and hardware version".
2. Select slot no, view the ONU type and software and hardware versions.




Figure 11-59 ONU Type and software and hardware versions

### 11.7.4. Check OLT link status

#### Function

Check OLT link status.

#### Operating Procedure

1. Right click OLT, select "State Callbacks">>"check OLT link status", check OLT link status.




Figure 11-60 Check OLT link status

### 11.7.5. Slot work state info

#### Function

View slot work state information.

#### Operating Procedure

1. Right click OLT, select "State Callbacks">>"slot work state info".
2. View CPU usage and memory usage.

Slot	CPU Usage(%)	Memory Usage(%)
04	0.26	26.61
07	0.0	0.0
14	0.19	26.59

Figure 11-61 Slot work state info

## 11.7.6. RSTP

### 11.7.6.1. RSTP Bridge

#### Function

View RSTP Bridge

#### Operating Procedure

1. Right click OLT, select "State Callbacks">>"RSTP">>"RSTP bridge".




Figure 11-62 RSTP Bridge

### 11.7.6.2. RSTP port info

#### Function

View RSTP port info

#### Operating Procedure

1. Right click OLT, select "State Callbacks">>"RSTP">"RSTP port info".




Figure 11-63 RSTP Port info

## 11.8. View current/History alarm

### Function

Input query condition, query current/history alarm.

### Operating Procedure

1. Right click OLT, select "view current alarm "or" view history alarm", pop-up alarm query interface.
2. Click "reset condition" set query condition.
3. Click "query", pop-up alarm query result.
4. Alarm query result is displayed by alarm query list and alarm statistics result.




Figure 11-64 Reset alarm query condition




Figure 11-65 Alarm query list




Figure 11-66 Alarm statistics result

## 11.9. View real-time performance

### Function

View real time performance

### Operating Procedure

1. Right click OLT, select "view real time performance" pop-up view real time performance interface.
2. Select destination ports and performance parameter.
3. Set interval time and group by.....
4. Clicking "Add" button start to gather real time performance.
5. Choose expression of you like from right box.




Figure 11-67 View real time performance

## 11.10. Ping NE

### Function

Test to see if the link between equipment and network management system is

working well.

### Operating Procedure

1. Right click OLT, select "ping NE" pop-up ping NE interface.

The screenshot shows a Windows command prompt window titled 'C:\WINDOWS\system32\ping.exe'. The window contains the following text:

```
Pinging 192.168.3.223 with 32 bytes of data:  
Reply from 192.168.3.223: bytes=32 time<1ms TTL=64  
Reply from 192.168.3.223: bytes=32 time<1ms TTL=64
```

At the bottom of the window, there is a status bar with the text '搜狗拼音 半:'.

Figure 11-68 Ping NE

## 11.11. Telnet NE

### Function

Telnet

### Operating Procedure

1. Right click OLT, select "telnet NE" pop-up telnet interface.
2. You can use command to configure in the interface.




Figure 11-69 Telnet NE



## 12. ONU management

This chapter describes the function of ONU management. It mainly includes the following contents:

- ONU detail
- NE rename
- View management
- Sync device
- Configuration
- Operation
- Control command
- Real time info
- Operation
- User business configuration

## 12.1. ONU detail

### Function

ONU detail is used to manage and control ONU. It mainly includes ONU basic info, ONU user info and ONU port list.

### Operating Procedure

1. Right click ONU, select "ONU detail" enter ONU detail interface.
2. Clicking "ONU basic info", "ONU user info", "ONU port list" in turn to set.




Figure 12-1 ONU Detail

## 12.2. NE rename

### Function

Set user label of ONU.

### Operating Procedure

1. Right click ONU, select "NE rename" enter rename interface.

2. Input user label and click "OK" to complete setup.




Figure 12-2 NE Rename

## 12.3. View management

### 12.3.1. Chassis view

#### Function

Chassis view Intuitive shows port position and state information of the ONU.

#### Operating Procedure

1. Right click ONU, select "View management">>"chassis view" enter chassis view interface.




Figure 12-3 ONU Chassis view

### 12.3.2. Device physical map

#### Function

Device physical map shows how devices be connected with each other.

#### Operating Procedure

1. Right click ONU, select "view management" >"device physical view" enter device physical view interface.
2. Can use toolbar, right-click menu to manage device physical map




Figure 12-4 ONU Device physical view

### 12.3.3. Move...

#### Function

Move network element, domain or group into other domain or group.

#### Operating Procedure

1. Right click ONU, select "view management" >"Move To..."enter move... interface.
2. Select network element which you need, click "OK" to move where you want.




Figure 12-5 move onu

## 12.4. Sync device

### Function

Sync device can ensure configuration of equipment and configuration of network management. When the configuration changes, we can manually sync it.

### Operating Procedure

1. Right click ONU, select "sync device" enter synch state.
2. In the process of synchronous, background synchronization information will be printed in the rolling log interface. Once getting an error message, it will show problem immediately.



Figure 12-6 Sync device

3. If synchronous failure, device would have "!" Warning users on top right corner.

## 12.5. Configuration

### 12.5.1. ONU port MAC number limit

#### Function

Set ONU port MAC number limit

#### Operating Procedure

1. Right click ONU, select "configuration">>"ONU port MAC num limit" enter ONU port MAC number list interface.




Figure 12-7 ONU Port MAC num limit

## 12.5.2. RSTP enable

### Function

Used for control RSTP opening or closing

### Operating Procedure

1. Right click ONU, select "configuration">>"RSTP enable" enter RSTP enable interface.
2. Set RSTP enable




Figure 12-8 RSTP Enable interface

### 12.5.3. DBA parameters management

#### Function

Set DBA parameters of the ONU

#### Operating Procedure

1. Right click ONU, select "configuration">>"DBA parameters management", enter DBA parameters interface.
2. You can add or delete according to the actual needs of the items. And then click "save", "refresh" in turn to complete.




Figure 12-9 DBA Parameters management interface

## 12.6. Control command

### 12.6.1. ONU performance reset

#### Function

Reset ONU performance statistics

#### Operating Procedure

1. Right click ONU, select "control command">>"ONU performance" enter ONU performance reset interface.
2. Click "OK" button to execute operation.




Figure 12-10 Clear ONU performance statistics

## 12.7. Operation(O)

### 12.7.1. Reregister ONU

#### Function

Reregister ONU

#### Operating Procedure

1. Right click ONU, select "operation (o)">"reregister ONU" to register ONU interface.




Figure 12-11 ONU reregister

2. When ONU reregister successful, rolling log bar will print the message of process.

[System Message] 2012-03-16,09:57:41 ONU\_REGISTER 192.168.3.29-14/02:33 success

Figure 12-12 Tips of reregister ONU

## 12.7.2. Reset ONU

### Function

Reset ONU

### Operating Procedure

1. Right click ONU, select "operation (o)">"reset ONU" to reset ONU.

[System Message] 2012-03-16,10:00:10 ONU\_RESET 192.168.3.29-12/03:65 success

Figure 12-13 Tips of reset ONU

## 12.7.3. Delete ONU

### Function

Delete ONU

### Operating Procedure

- Right click ONU, select "Operation (O)">"delete ONU" to delete ONU.




Figure 12-14 Delete ONU

- The result of delete operation will be displayed in rolling log bar as the same time, for successful authorized ONU, network management will delete ONU and updated status in the logic topo map, as below.

```
[System Message] 2012-03-16,10:01:49 ONU_DELETE 14/02:33 58-54-04-00-01-98 success
```

Figure 12-15 Tips of delete ONU

### 12.7.4. Device to linkup

#### Function

Set device linkup

### Operating Procedure

- Right click ONU, select "Operation (O)">"device to linkup" to set device linkup.




Figure 12-16 Set device linkup

## 12.8. State Call backs

### 12.8.1. ONU port MAC table

#### Function

View ONU port MAC table

#### Operating Procedure

1. Right click ONU, select "real time info">>"ONU port MAC table" enter ONU MAC table list interface.
2. Choose port from left tree. Click to view.




Figure 12-17 ONU Port MAC table

### 12.8.2. Device information

#### Function

Display device information

#### Operating Procedure

1. Right click ONU, select "real time info">>"device information", enter device information.




Figure 12-18 Device info

### 12.8.3. Capability information

#### 12.8.3.1. FEC function

##### Function

Set FEC function query.

##### Operating Procedure

1. Right click ONU, select "real time info">>"capability">"FEC function" enter FEC function interface.




Figure 12-19 FEC Function

## 12.8.4. Link test


### 12.8.4.1. POTS port outer test

#### Function

ONU external line status query language can be used in fault diagnosis.

#### Operating Procedure

1. Right click ONU, select "real time info">>"link test ">"pots port outer test"  
enter pots port outer test interface.
2. You can set test type is forced/not forced.



Slot No	ONU No	POTS No	Test Type	Test State	Refused R...	Port State	A to Ground...	B to Groun...	A to B DC V...	A to Grou...
14	33	1	Forced	Succeed		Normal				

Figure 12-20 Pots port outer test

#### 12.8.4.2. POTS port inner test

##### Function

ONU internal language line status query can be used in fault diagnosis.

##### Operating Procedure

1. Right click ONU, select "real time info">>"link test ">"pots port inner test" enter pots port inner test interface.
2. You can set test type is forced/not forced.




Figure 12-21 Pots port inner test

## 12.9. Operation(N)

### 12.9.1. FE port loop back

#### Function

FTTH ONU on the specified port type of loop back operation, loop back direction of the designated port for the ONU to the OLT side.

#### Operating Procedure

1. Right click ONU, select "real time info">>"FE Port Loop Back", enter the interface and set the port No.




Figure 12-22 FE Loop Back

### 12.9.2. FE port auto-negotiation

#### Function

Force FE port auto-negotiation.

#### Operating Procedure

1. Right click ONU, select "real time info">>"FE Port Auto-negotiation", enter the interface, and set the port No.




Figure 12-23 Force auto-negotiation

### 12.9.3. User business configuration

#### Function

Set user business configuration.

#### Operating Procedure

1. Right click ONU, select "real time info">>"user business configuration" enter the interface.
2. Configure ONU business parameters, such as port information, flow control, vlan and port bind.
3. Set parameters, click "save configuration" to complete.




Figure 12-24 User business configuration

## 13. FAQ

This chapter describes FAQ in operation.

**Q1: What are the default user, password and port number of the Server?**

**A:** The default user and password is root, port number is 5188.

**Q2: What processes network management system include?**

**A:** Client includes javaw, SBI includes javaw, and Server includes javaw, mysqld and java (joram).

**Q3: What about preconditions of normal operating network management system?**

**A:** Device and network management network is reachable, you can use ping and telnet to verify. At the same time you must be sure the SNMP agent on device is turned on and the SNMP Community is configured correctly.

**Q4: What are the possible reasons if the network management Server can not start?**

**A:** Possible reasons are the following:

- ✧ The Server has not been installed successfully.
- ✧ Operating System is too old or too new. Recommendations for the use of Windows XP operating system.
- ✧ The Server service port is occupied by other software.